

Twin Underbench

Replacing Cartridges including fluoride removal XF934

1. Turn off water supply valve under sink, found on small tubing inlet side of filter
2. Release pressure by opening filter tap on sink and leave open for duration of process
3. Using filter spanner, undo both inlet and outlet side housing and discard old cartridges
4. Insert new XF934 cartridge to inlet side housing **
5. Retighten both housings leaving outlet side empty
6. Turn water back on and allow water to flow (flushing) for five minutes.
7. Turn water off and insert new carbon cartridge to outlet side housing ***
8. Retighten outlet side housing, turn water back on and flush for 5 minutes.
9. Inspect for any leaks

** When inserted into housing XF934 **MUST** have writing facing up (written on cartridge "this end up"). XF934 **MUST** be flushed first before inserting outlet side cartridge.

*** Carbon block cartridge can be inserted anyway up. Mountain Stream Designer cartridge **MUST** be inserted with wider section (checker plate end) facing up.

Clean inside of empty housing before inserting cartridges

