

Twin Underbench

Replacing Cartridges including a sediment and carbon type cartridge

1. Turn off water supply valve under sink, found on small tubing inlet side of filter.
2. Release pressure by opening filter tap on sink and leave open for duration of process.
3. Using filter spanner, undo both inlet and outlet side housing and discard old cartridges.
4. Place new sediment cartridge to inlet side housing (anyway up is fine).
5. Using filter spanner, undo outlet side housing (going to filter tap) and discard old cartridge.
6. Place new carbon type cartridge to outlet side housing**.
7. Retighten both housings.
8. Turn water back on and allow water to flow (flushing) for five minutes.
9. Inspect for any leaks.

** Carbon block cartridges can be inserted anyway up. Mountain Stream Designer cartridge (Red, Blue, Green) MUST be inserted in housing with wider section (checker plate end) facing up. Ceramic cartridge MUST be inserted with writing facing up. Intermittently as required clean ceramic cartridge with scouring brush/cloth. Clean inside of empty housing before inserting new cartridges.

