

Counter top systems - Cartridge replacement

1. Using filter spanner, undo housing and discard old cartridge.
2. Clean inside of now empty housing before inserting new cartridge.
3. Insert new cartridge in housing.**
4. Retighten housing.
5. Turn on and allow water to flow (flushing) for five minutes.
6. Inspect for any leaks.

Mountain Stream Designer Cartridges (red, blue, green) MUST be inserted in the now empty housing with wider section (checkerplate end) facing up. *

** Carbon block cartridges can be inserted anyway in now empty housing.

** Ceramic Cartridge MUST be inserted in now empty housing with writing facing up. ****

