

Twin Underbench

Replacing Mountain Stream Resin Ion Exchange Cartridges (red)

12 MONTH FILTER REPLACEMENT FOR BOTH RESIN CARTRIDGES

1. Turn off water supply valve under sink, found on small tubing inlet side of filter
2. Release pressure by opening filter tap on sink and leave open for duration of process
3. Using filter spanner, undo inlet side housing and discard old cartridge
4. Place new resin cartridge to inlet side housing**
5. Retighten housing
6. Turn water back on and allow water to flow (flushing) for five minutes.
7. Turn off water supply again and repeat steps 2-6 with outlet side housing (going to filter tap)
8. Inspect for any leaks

Mountain Stream Designer Cartridges **MUST be inserted in the housing with wider section (checker plate end) facing up.

Clean inside of empty housing before inserting cartridge

