

## Twin Underbench

Replacing Mountain Stream Resin Ion Exchange Cartridges (red)

### 6 MONTH FILTER REPLACEMENT WHEN CHANGING ONE RESIN CARTRIDGE ALTERNATING

1. Turn off water supply valve under sink, found on small tubing inlet side of filter
2. Release pressure by opening filter tap on sink and leave open for duration of process
3. Using filter spanner, undo inlet side housing and discard old cartridge
4. Using filter spanner, undo outlet side housing (going to filter tap) and carefully remove cartridge and place in the now empty inlet side housing \*\*
5. Place new resin cartridge to outlet side housing \*\*
6. Retighten both housings
7. Turn water back on and allow water to flow (flushing) for five minutes
8. Inspect for any leaks

\*\*Mountain Stream Designer Cartridges **MUST** be inserted in the housing with wider section (checkerplate end) facing up.

Clean inside of empty housing before inserting cartridge

