

## Replacing Inline, Female end filter

Applies to ALL female filter ends including Carbon and Alkalising filter types.

1. Turn off water supply under sink, found on small tubing inlet side of filter.
2. Release pressure by opening either, filter tap on sink or glass dispenser of fridge.
3. Remove red clips if present.
4. Pushing the Small Outer Ring of filter at the same time slowly pull on tube, and tube will be removed from filter (please note if Small Outer Ring is not pushed in, tube will NOT come out).
5. Using a wrench unscrew the fittings at either end of the filter, it may be a straight fitting or a elbow type fitting.
6. With both fittings removed now discard the old filter.
7. Place a small amount of Teflon tape around the two fittings, remove dust caps on either end of filter. Screw the two fittings back into the new filter.
8. Connect water supply side to inlet side of filter (be careful to take notice of arrow on filter). Arrow will be on filter in direction of water flow.
9. BEFORE connecting outlet side, if applicable, place a bucket under filter and slowly turn on water supply to flush filter 1-2 minutes into bucket.
10. After flushing, re connect outlet side (going to fridge or filter tap).
11. Refit red clips.
12. Inspect for any leaks.

**IMPORTANT** When reconnecting to tube side of fitting, make sure tube is fully pushed into fitting

